

Atrie DB108 ADSL MODEM

User Manual

V1.0

CONTENTS

1.OVERVIEW.....	3
1.1 ABOUT ADSL.....	3
1.2 ABOUT ADSL2/2+.....	3
1.3 FEATURES.....	3
2 SPECIFICATION.....	4
2.1 INTERFACE INTRODUCTION	4
2.1.1 INDICATOR AND INTERFACE.....	4
2.1.2 SPLITTER SPEC.....	4
2.2 HARDWARE CONNECTION	4
2.3 LED STATUS INDICATION.....	5
3.CONFIGURATION.....	6
3.1 DEFAULT CONFIGURATION.....	6
3.2 COMPUTER CONFIGURATION.....	6
3.3 ADSL MODEM CONFIGURATION	6
3.3.1 LOG IN.....	6
3.3.2 SAVE SETTING.....	7
3.4 WAN CONFIGURATION	7
3.4.1 CONFIGURATION GUIDE.....	7
3.4.2 RFC1483 BRIDGE CONFIGURATION.....	9
3.4.3 PPPoE CONFIGURATION.....	11
3.4.4 STATIC ADDRESS	12
4 OTHER CONFIGURATION	13
4.1 LAN CONFIGURATION	13
4.1.1 CONFIGURATION OF MODEM'S IP ADDRESS.....	13
4.1.2 DHCP CONFIGURATION	13
4.2 PASSWORD CONFIGURATION.....	14
5. TROUBLESHOOTING	15
5.1 UNABLE TO ACCESS INTERNET	15
5.1.1 CHECK THE LINE AND THE DEVICE	15
5.1.2 CHECK YOUR CONFIGURATION	15
ANNEX : SHIPPING LIST.....	16

1.OVERVIEW

1.1 ABOUT ADSL

An ADSL MODEM is a broadband Internet access device, which utilizes the high frequency segment of the phone line to transmit high-speed data without affecting the voice transmission. The frequency of the ADSL signal is higher than that of voice, so voice and ADSL signal can coexist in one line by using a splitter to insulate each from the other. ADSL data transfer adapts the asymmetry model. It supports upload transmission speed up to 1Mbps and download speed up to 8 Mbps (24Mbps for ADSL2+). ADSL is an ideal device for broadband access.

1.2 ABOUT ADSL2/2+

Transmission performance of ADSL2 is improved comparing with the first generation of ADSL. These improvements are mainly concerned with long distance, anti-line-loss, anti-noise, etc. By doubling the transmission bandwidth, ADSL2+ has implemented a downlink rate as high as 24 Mbps. Therefore, Internet applications such as synchronous transmission of multi video stream, online games and huge capacity of downloading files are made possible.

1.3 FEATURES

- 1、 Support ANSI T1.413 ISSUE 2、 ITU G.992.1 (G.DMT)、 ITU G.992.2 (G.LITE)、 ITU G.992.3、 ITU G.992.5
- 2、 Web-based configuration and monitoring.
- 3、 Support up to 4 PVCs.
- 4、 Routing function.
- 5、 NATP、 DHCP function.
- 6、 Maximum downstream transmission rates of 8 Mbps (24Mbps for ADSL2+) .
- 7、 Maximum upstream transmission rates of 1Mbps
- 8、 Transmission distance up to 5.5 km.

2 SPECIFICATION

2.1 INTERFACE INTRODUCTION

2.1.1 INDICATOR AND INTERFACE

Table 2.1

ITEM	Name	State introduction
Indicator	POWER	A steady red light means the power connection works properly
	LINK	Yellow, shows DSL line status.
	DATA	Green, Flashing means the Modem is transmitting or receiving data
	PC	Green, Indicates status of connection to the PC network card
Interface	LINE	Connected with phone line or “ADSL” port of the splitter.
	ETHERNET	To be connected to a PC network card by a straight-through network cable, also can use a crossover cable to connect to Hub, Switch or Router.
	POWER	Power interface, Connect with power adapter.
	RST	Reset to default setting. Put a pin into the eyelet, and press the button hidden in the modem, then you can reset the modem with the default value.
	SWITCH	To turn on / off the power.

2.1.2 SPLITTER SPEC

Table 2.2

Interface	Introduction
LINE	Connected with telephone line
ADSL	Connect with the LINE port of the ADSL Modem using telephone line provided.
PHONE	Connect with telephone

2.2 HARDWARE CONNECTION




Figure 2.1

Introduction :

- 1、 Use a telephone cord to connect the LINE port of the splitter with the RJ-11 port (the phone jack) on the wall.
- 2、 Use another telephone cord to connect the ADSL port of the splitter with the LINE port of the ADSL Modem.
- 3、 Use another telephone cord to connect the telephone set with the PHONE port of the splitter.
- 4、 Connect Ethernet port of the ADSL MODEM with 10/100BASE-T port of the computer using the network cable that comes with the modem.
- 5、 Plug in the power cord, and turn on the power.

If you do not want Internet services and telephone voice services simultaneously, please just connect the LINE port of the ADSL Modem with the RJ-11 port (the phone jack) on the wall using a telephone cord. In this case, the splitter is not necessary.

2.3 LED STATUS INDICATION

Table 2.3

Status	POWER (red)	LINK (yellow)	DATA (green)	PC(green)
Steady light	Power on	The modem is in good connection	Connected with PC	Ethernet line is connected
Flashing	/	In handshaking status	/	/
Fast flashing	/	/	Transmitting or receiving data	Transforming data
Off	Power off	Connection not set up	Not connected with PC properly	Ethernet line not connected properly

3.CONFIGURATION

3.1 DEFAULT CONFIGURATION

ADSL MODEM has pre-configured with the following VCI/VPI. The default dial-up mode is bridge encapsulation. For bridge mode, no need to configure any more parameter. However, the third party dial-up software is needed for connection with the Internet

Tabel 3.1

Link Name	VPI	VCI
pvc_0_32	32	0
pvc_8_35	35	8
pvc_0_35	35	0
pvc_8_81	81	8

3.2 COMPUTER CONFIGURATION

The default IP address for ADSL MODEM is: **192.168.1.1**; The Subnet Mask is : **255.255.255.0**. Users can configure ADSL MODEM through an Internet browser. ADSL MODEM can be used as gateway and DNS server; users need to set the computer's TCP/IP protocol as follow:

- 1、 Set the computer IP address at same segment of ADSL MODEM, such as set the IP address of the network card to one of the “192.168.1.2”~ “192.168.1.254”.
- 2、 Set the computer's gateway the same IP address as the ADSL Modem's.
- 3、 Set computer's DNS server the same as ADSL Modem's IP address or that of an effective DNS server.

3.3 ADSL MODEM CONFIGURATION

3.3.1 LOG IN

Open the browser; input **http://192.168.1.1** at the address column. Press “Enter” key then the entry dialog box will show up as Figure 3.1. Input “username” and “password” (capital sensitive), then press Enter.




Figure 3.1

3.3.2 SAVE SETTING

After getting through each page for parameters setting, click “Save” or “Save apply” to store the value in ADSL MODEM. Briefly, we named “Save”.

Note :

When you save the settings, the web page will be refreshed slowly, please wait it finished.

After you save the settings, it will take effect until next reboot.

Some settings only take effect after rebooting the router.

3.4 WAN CONFIGURATION

If the configuration is bridge encapsulation, there is no need to configure any more parameters. Only need to use the third party dial-up software to connect the Internet.

Totally, this router supports :PPPoA, PPPoE, MER, IpoA, Bridging. For detail configuration information, please check the following configuration guide.

3.4.1 CONFIGURATION GUIDE

Click “WAN” on the left page, enter into “WAN” configuration page.

- Note: At most we can have four connections. If you need to add a new connection, please delete or modify an existing connection.




Figure 3.2

Click on the next connection which you want modify. Press “Edit” button, enter the configure guide, as Figure 3.3




Figure 3.3

- The value for VPI/VCI is assigned by your ISP. After inputting the PVC value, press “Next” into “connection type”. As Figure 3.4.




Figure 3.4

The Modem supports five ADSL protocol modes. Choose the protocol which is appointed by ISP and PVC encapsulation, click “Next” enter to the protocol configure. Below, we introduce the configuraion of the five protocol modes.

- PPP over ATM (PPPoA)
 - MAC Encapsulated Routing (MER)
 - Bridging
 - PPP over Ethernet (PPPoE)
 - IP over ATM (IPoA)
- Some connection lines need to confirm the LLC or VC, if you can’t confirm, please don’t modify the default value or ask your ISP.

3.4.2 RFC1483 BRIDGE CONFIGURATION

Select the Bridging mode. Then press “Next” to specify the Service Name, and select the “Enable Service” as Figure 3.5.




Figure 3.5

Press “Next” to enter into “WAN configuration”, click “save” to save configuration, if you need to modify the parameter, click “back” as Figure 3.6.




Figure 3.6

Note : When you use bridge mode, please close "DHCP SERVER", the result as Figure 3.7




Figure 3.7

3.4.3 PPPOE CONFIGURATION

PPPoE is also known as RFC 2516. It is a method of encapsulating PPP packets over Ethernet.

PPPoA is also known as RFC2364 and named as Peer to Peer Protocol over ATM. As PPPoE, it also has all the features of PPP. Although it's based on ATM protocol, the setting of all the other parameters is similar with PPPoE. So we only introduce PPPoE in detail here.

In Figure 3.4, select PPP over Ethernet (PPPoE), press “Next step” entering the configuring interface, as Figure 3.8.




Figure 3.8

- PPP Account: Your account from ISP to access Internet.
- Password: Input the password assigned by your ISP.
- PPPoE server name: Server name of network ISP. No need to set.
- Authentication Mode: Authentication mode of network ISP. Default is AUTO.
- Connection on demand: When this mode is selected, the connection that has no traffic within assigned disconnect timeout (e.g. 1 minute) will be automatically disconnected. The connection will be activated again when traffic arrives. This function is advantageous for users who are charged with online time. It should be noticed that some programs automatically link to Internet. Computer will send data to network when infected by virus. Connection will not be disconnected under these data streams.
- Disconnect timeout: When “Connection on demand” is selected, this input box indicates that after how long the connection will be disconnected in the absence of traffic. If the value is 0, connection will not be disconnected.

Press “Next step” when configuration is finished. The following operation is same with Figure 3.5. Notice that PPPoE mode does not work until the modem is reset.

3.4.4 STATIC ADDRESS

In Figure3.4, select MAC Encapsulation Routing (MER), press “Next”, and the configuration can be queried from your ISP, the result as Figure3.9.




Figure 3.9

4 OTHER CONFIGURATION

4.1 LAN CONFIGURATION

Configuration of Modem's IP address and password

4.1.1 CONFIGURATION OF MODEM'S IP ADDRESS

As a network device, ADSL Modem has its own IP address and MAC address. The factory sets the MODEM, at a default IP address of 192.168.1.1 and subnet mask of 255.255.255.0. The user can configure these addresses through the "LAN" on "Configuration" like this:

For example, change IP address to "10.10.10.10". Click "LAN", input "IP address": 10.10.10.10, then "subnet mask": 255.0.0.0, the result is as Figure4.1, press "save".




Figure 4.1

Note : If you change IP address, it will take effect immediately. You must use the new IP address to login.

4.1.2 DHCP CONFIGURATION

- click "LAN "
- click "DHCP server" ;

- Define the “Start IP address” and the “End IP address” of DHCP server (for example, from 192.168.1.2 to 192.168.1.254).
- Input the value of lease (Measured by the second, 0 indicates permanently valid).

As Figure 4.2, open DHCP server, computer will set the IP Address of network card with one of the address 10.10.10.11 ~ 10.10.10.254.

DHCP Server

☐ Disable

☒ Enable

Start IP Address: 10.10.10.11

End IP Address: 10.10.10.254

Leased Time(hour): 2

Save Reset

Figure 4.2

Note : When you use the DHCP Server, please pay attention to having multi-DHCP Server in one LAN.

4.2 PASSWORD CONFIGURATION

When you configure ADSL MODEM through an Internet browser, the system requires user name and password to validate access permission. The factory sets the modem at a default username of “**admin**” and the password of “**password**”. The username is unchanged. You can enter the “password configuration” on Configuration column to change the password.

Attention: please remember the password after change, otherwise you will not be able to change configuration after saving setting

5. TROUBLESHOOTING

5.1 UNABLE TO ACCESS INTERNET

5.1.1 CHECK THE LINE AND THE DEVICE

- 1、 Check the indicator of power supply is on, if not, Make sure the connection of power supply is correct; Make sure the output of power supply is correct; Make sure the switch of power supply is turned on ;
- 2、 Check the indicator of PC is on, if not, Make sure the connection of cable and network adapter; Make sure that the correct cable is used;
- 3、 Check the LINK LED to see if it is twinkling. If no fast twinkling is observed within 3 minutes, please check whether phone line has been correctly placed; whether ADSL separator is correctly used. If multiple extensions have been installed, make sure that the separator is installed prior to the junction box of phone line. If the above items are confirmed and still no fast twinkling of WAN LED is observed, call the ISP to query whether ADSL service has been provided on your line;
- 4、 Check the LINK LED to see whether it is unable to change status from fast twinkling to always light, or whether it changes status to fast twinkling after sometime of always light. If these phenomena occur constantly, please contact your ISP with a demand to check lines and signal quality;

If there is no problem in the above items, the line and the device shall be working. Problems may come from your computer configuration or device configuration.

5.1.2 CHECK YOUR CONFIGURATION

We explain here the configuration of PPPOE using Windows 2000 operation system as an example. For other operation systems the process is similar.


- 1、 Enter the device manager to check if Ethernet adapter is correctly installed. If any problem exists, please re-installed it;
- 2、 Check the configuration of Ethernet adapter in PC. Try to manually set IP address that is in band 192.168.1.x without conflict. See 3.2;
- 3、 Try to run command “ping 192.168.1.1” on command line mode. If the response returns “time out”, please check Ethernet connection and IP settings;
- 4、 If this modem is reachable, try to run ping with a known outer IP, e.g. the DNS server IP of ShangHai Online: “ping 202.96.209.133”.
 - If ping is reachable, there shall be no problems in the modem. Please see step 5;
 - If ping is not reachable, see step 6 and check if the configuration is correct.
- 5、 Please try to ping a certain outer URL, e.g. “ping www.google.com”.
 - If ping is reachable, there shall be no problems in the network settings. Please check the settings of the PC terminal, e.g. whether the security level is too high, or whether anti-virus firewall is installed;
 - If ping is not reachable, check the DNS setting of Ethernet adapter. See 3.2.

Note 1 : The precondition is that LAN settings in the modem has not been modified.

Note 2 : We usually start command line mode in Windows 2000 as follows: click on the “RUN” item of Windows Start Menu, input characters “cmd” in the input box popped up with an “Enter”. The window

subsequently popped up is the command line window.

Note 3 : The returned values of ping command in the following format show the standard of “reachable”



```

H:\WINNT\system32\cmd.exe
H:\>ping 192.168.1.1

Pinging 192.168.1.1 with 32 bytes of data:

Reply from 192.168.1.1: bytes=32 time<10ms TTL=255
Reply from 192.168.1.1: bytes=32 time<10ms TTL=255
Reply from 192.168.1.1: bytes=32 time<10ms TTL=255
Reply from 192.168.1.1: bytes=32 time<10ms TTL=255

Ping statistics for 192.168.1.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

H:\>
  
```

Figure 5.1

If ping of the modem is reachable but ping of the outer fixed IP is unreachable, attention should be concentrated upon device settings. Please enter the configuring interface following the instructions in this manual.

- (1) Check first the number of connections. If more than one connection exists, for troubleshooting , delete unused connections and remain the one connection you are using.
- (2) Check the connection to see whether correct “type” is selected. It’s normal to choose login type of PPPoE. When you use PPPoE to login, the following information should be provided: VPI and VCI, which can be queried from your ISP, user name and password.
- (3) Then make sure that “using NAT” and “default gateway” have been selected with a tick. Check whether “connect on demand” has been selected with a tick. If it is selected, the connection is activated only when traffic to outer networks arrives. If not selected, check “keep connection”, which should be set to 0 if you demand to keep connection

Make sure that the above parameters are saved after configuration. Internet is now available since the configuration is properly done.

ANNEX : SHIPPING LIST

ADSL MODEM	× 1
Splitter	× 1
User Manual	× 1
Power Supply	× 1
Cable Cat5 RJ45	× 1
Telephone Line	× 2



Atrie Technology Pvt. Ltd.

Corporate office: Atrie House, # 591,3rd Block, Koramangala, Bangalore -560 034 India

Registered office: #B-121,Ground Floor ,Kalkaji, New Delhi – 110019

Regional office (West): #C/312,3rd Floor, Gokul Arcade, Vile Parle(E) Subhash Road,Mumbai - 400057

Web: <http://www.atrindia.com>

Email: contacts@atrindia.com

